7LED PAR Light -3IN1



LED Stage Lighting Operating Manua

Technical:

Voltage: AC110-220V 50/60HZ Power supply: 80W

Light source: 9W*7PCS Color: RGB 3IN1 LEDs

Channel:7/3CH

Operation: DMX512, Auto, Sound, Master-slave Package: 12PCS/CARTON

Thank you so much to choose this product; it is adopting the most advanced lamps, which is called LED lamps. It conquers a lot of disadvantages such as power wasting, short using life, high temperature, etc. It has advantages of power saving, long life (it can reach 60,000.00 hours in general cires), high brightness, fresh colors...It is the best stage illuminating and various effect decorative products.

DMX512Control: 7 Channel Model(A001)

CH7			CIIO	CHX			CHS	CH4	CH3	CH2	CHI	СН
Function speed			T. MICHOIL CHOICE	Function choice			Strobe	B dimmer	G dimmer	R dimmer	Dimmer	Display
Speed function, from slow to fast	251~255: Sound-Active	201~250: Colors Pulse Change.	151~200: Colors Gradate.	101~150: Colors Jump Change.	51~100: Different Colors Output	0~50: DMX 8CH Control.	R. G. B strobe: from slow to fast	B dimmer: from dark to bright	G dimmer: from dark to bright	R dimmer: from dark to bright	R. G. B dimmer: from dark to bright	Function

DMX512Control: 3Channel Model(D001)

CH3	CH2	CH1	Channel
B Dimmer	G Dimmer	R Dimmer	Function
Dimmer- Dark to Bright	Dimmer- Dark to Bright	Dimmer- Dark to Bright	Instruction

FUNCTION:

No Show		TOOD	1001	TOON		3 r255	r255 G255	r255 G255 b255	r255 G255 b255 FH99	r255 G255 b255 FH99 CL01	r255 G255 b255 FH99 CL01	r255 G255 b255 FH99 CL01 CC99 DE99	r255 G255 b255 FH99 CL01 CC99 DE99
Function	DMX Address	(001~512)	DMX Address	(001~512)	Red (000~255)		Green (000~255)	Green (000~255) Blue (000~255)	Green (000~255) Blue (000~255) Strobe flash (01~99)	Green (000~255) Blue (000~255) Strobe flash (01~99) Different Colors Output (01~08)	Green (000~255) Blue (000~255) Strobe flash (01~99) Different Colors Output (01~08) Colors Jump Change (01~99)	Green (000°255) Blue (000°255) Strobe flash (01°99) ifferent Colors Output (01°08) lors Jump Change (01°99) Colors Gradate (01°99)	Green (000°255) Blue (000°255) Strobe flash (01°99) ifferent Colors Output (01°08) lors Jump Change (01°99) Colors Gradate (01°99) Colors Pulse Change (01°99)
	DMX-512	Channels	DMX-512	Channels	UP, DOWN Change	UP, DOWN Change		UP, DOWN	UP. DOWN Change	UP, DOWN UP, DOWN	UP. DOWN Change UP. DOWN Change UP. DOWN Change	UP, DOWN Change UP, DOWN Change UP, DOWN Change UP, DOWN Change	UP, DOWN UP, DOWN UP, DOWN UP, DOWN UP, DOWN
Instruction	address	mode	address	mode		Change bri		UP, DOWN Change brightness	Change bri	UP, DOWN Change brightness UP, DOWN Change the speed UP, DOWN Change brightness	Change bri	Change the Change the Change the Change the Change the Change the	UP, DOWN Change the speed UP, DOWN Change the speed UP, DOWN Change brightnes UP, DOWN Change the speed UP, DOWN Change the speed UP, DOWN Change the speed
	set, 3		set, 7		brightness	brightness		ightness	ightness e speed	s speed s speed	ightness ightness	ightness ightness ightness e speed	s speed speed